



PELLET STOVE

FLAT

COMFORT AIR MADE OF CERAMICS



RELAX

FLAIR

COMFORT AIR MADE OF STEATITE

Translation of original instructions

MCZ



8901220500

TABLE OF CONTENTS

TABLE OF CONTENTS	II
INTRODUCTION	1
1-WARNINGS AND WARRANTY CONDITIONS	2
2-INSTALLATION INSTRUCT	5
3-INSTALLATION AND ASSEMBLY	13
4-LCD REMOTE CONTROL	31
5-EMERGENCY PANEL.....	36
6-SAFETY DEVICES AND ALARMS.....	39
7-MAINTENANCE AND CLEANING	43
8-PROBLEMS/CAUSES/SOLUTIONS	47
9-WIRING DIAGRAMS.....	50

INTRODUCTION

Dear customer,
thank you for having chosen our product.

To allow for optimal operation and for you to enjoy the warmth and sense of wellbeing that the fire can convey in your home, we advise you to read this manual carefully before starting up the product for the first time.

REVISIONS TO THE PUBLICATION

The content of this manual is strictly technical and property of MCZ Group Spa.

No part of this manual can be translated into another language and/or altered and/or reproduced, even partially, in another form, by mechanical or electronic means, photocopied, recorded or similar, without prior written approval from MCZ Group Spa.

The company reserves the right to make changes to the product at any time without prior notice. The proprietary company reserves its rights according to the law.

CARE OF THE MANUAL AND HOW TO CONSULT IT

- Take care of this manual and keep it in an easily accessible place.
- Should the manual be misplaced or ruined, request a copy from your retailer or directly from the authorised technical assistance Department.
- **“Bold text”** requires particular attention.
- *“Text in italics”* is used to draw your attention to other paragraphs in this manual or any additional explanation.
- *“Note”* provides the reader with additional information.

SYMBOLS USED IN THE MANUAL

	ATTENTION: carefully read and understand the relative message because failure to comply with that which is written can cause serious damage to the product and put the user's safety at risk.
	INFORMATION: failure to comply with these provisions will compromise the use of the product.
	OPERATING SEQUENCES: sequence of buttons to be pressed to access the menus or make adjustments.
	MANUAL carefully read this manual or the relative instructions.

1-WARNINGS AND WARRANTY CONDITIONS



SAFETY PRECAUTIONS

- **Installation, electrical connection, functional verification and maintenance must only be performed by qualified or authorised personnel.**
- **Install the product in accordance with all the local and national laws and Standards applicable in the relative place, region or country.**
- **This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are supervised or trained on how to use the product by a person responsible for their safety.**
- Errors or incorrect settings can cause hazardous conditions and/or poor operation.
- Only fuel recommended by the company must be used. The product must not be used as an incinerator. It is strictly forbidden to use liquid fuel.
- The instructions provided in this manual must always be complied with to ensure the product and any electronic appliances connected to it are used correctly and accidents are prevented.
- The user, or whoever is operating the product, must read and fully understand the contents of this installation guide before performing any operation. Errors or incorrect settings can cause hazardous conditions and/or poor operation.
- Do not use the product as a ladder or supporting structure.
- Do not place laundry on the product to dry. Any clothes horses or similar objects must be kept at a safe distance from the product.
- **Fire hazard.**
- *All liability for improper use of the product is entirely borne by the user and relieves the Manufacturer from any civil and criminal liability.*
- Any type of tampering or unauthorised replacement with non-original spare parts could be hazardous for the operator's safety and relieves the company from any civil and criminal liability.
- Most of the surfaces of the product can get very hot (door, handle, glass, smoke outlet pipes, etc.). **Avoid contact with these parts unless adequate protective clothing is worn or appropriate means are used, such as heat protective gloves or cold handles.**
- **It is forbidden to operate the product with the door open or the glass broken.**
- The product must be powered by a system that is equipped with an effective earth system.
- Turn off the product in the event of a fault or malfunctioning.
- Accumulated unburned pellets in the burner after each "failed start-up" must be removed before starting-up again.
- Do not wash the product with water. Water could penetrate the unit and damage the electrical insulation, thereby causing electric shocks.
- Do not stand in front of the product for a long time. Do not overheat the room where the product is installed. This could affect your physical conditions and cause health problems.
- Do not put any fuel other than wood pellets in the hopper.
- Install the product in rooms that are adequately protected against fire and equipped with all the utilities such as supplies (air and electricity) and smoke outlets.
- If a fire breaks out inside the chimney, switch the appliance off, disconnect it from the mains and do not open the door. Then contact the competent authorities.
- The product and the ceramic/serpentine cladding must be stored in a place where there is no humidity and must not be exposed to the elements.
- It is recommended not to remove the feet that support the product in order to guarantee adequate insulation, especially if the flooring is made of flammable material.
- If the start-up system is faulty, do not force ignition with flammable materials.
- Special maintenance must only be performed by authorised and qualified personnel.
- Assess the static conditions of the surface on which the weight of the product will rest and provide suitable insulation if it is made of flammable material (e.g. wood, fitted carpet or plastic).

1-WARNINGS AND WARRANTY CONDITIONS

INFORMATION:

Please contact the retailer or qualified personnel authorised by the company to resolve a problem.

- Only fuel stipulated by the company must be used.
- Check and clean the smoke outlet pipes regularly (connection with the chimney).
- The product is not a cooking appliance.
- Always keep the cover of the fuel hopper closed.
- Keep this instruction manual in a safe place as it must accompany the product throughout its working life. If it is sold or transferred to another user, always make sure that the manual accompanies the product.

INTENDED USE

The product must only be used indoors.

The product only works with wood pellets.

WARRANTY CONDITIONS

The company provides a product warranty, **excluding the parts subject to normal wear** stipulated below, for a period of **two years** from the date of purchase, which is proven by a supporting document that contains the name of the seller and the date when the sale took place. Warranty cover is valid if the completed warranty is returned within 8 days and the product is installed and tested by a qualified installer, according to the detailed instructions provided in the instruction manual supplied with the product.

The term 'warranty' refers to the (free-of-charge) replacement or repairs of parts acknowledged to be faulty due to manufacturing defects.

RESTRICTIONS

The above-mentioned warranty does not cover parts of electrical and electronic components and fans, which are covered for 1 year from when the product is purchased, proof of which is provided as specified above. The warranty does not cover parts subject to normal wear, such as: gaskets, glass and all parts that can be removed from the firebox.

Replaced parts will be covered by the warranty for the remaining period of the warranty in force as from the date of purchase of the product.

EXCLUSIONS

Variations in colour of the painted or ceramic/serpentine parts and crazed ceramics do not constitute grounds for a claim as they are natural characteristics of the material and product use.

The warranty does not cover any part that may be faulty as a result of negligence or careless use, incorrect maintenance or installation that does not comply with the company's instructions (see the relative chapters in this user manual).

The company declines all liability for any damage which may be caused, directly or indirectly, to persons, animals or objects as a consequence of non compliance with all the prescriptions specified in the manual, especially warnings regarding installation, use and maintenance of the appliance.

If the product does not work correctly, contact your local retailer and/or importer.

Damage caused during transport and/or when handled is excluded from the warranty.

The supplied installation guide is the only reference for installation and product use.

The warranty will be rendered null and void in the event of damage caused by tampering, atmospheric agents, natural disasters, electrical discharges, fire, defects in the electrical system, and maintenance not being performed as indicated by the manufacturer.

1-WARNINGS AND WARRANTY CONDITIONS

INTERVENTION REQUEST



The company declines all liability if the product and any other accessory is used incorrectly or altered without authorisation.

All parts must be replaced with original spare parts.



The request must be sent to the retailer who will forward it to the Technical Assistance Department.

SPARE PARTS

Only original spare parts must be used. The retailer or service centre can provide all the useful information regarding spare parts. It is recommended not to wait for the parts to be worn before having them replaced. It is important to perform regular maintenance.

PRECAUTIONS FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE 2002/96/EC AND ITS SUBSEQUENT AMENDMENT 2003/108/EC.



At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special differentiated waste collection centre set up by the local authorities or to a retailer that provides this service. Disposing of the product separately prevents possible negative consequences for the environment and health deriving from inappropriate disposal and allows its materials to be recovered in order to obtain significant savings in energy and resources.

As a reminder of the need to dispose of appliances separately, the product is marked with a crossed-out wheeled dustbin.

2-INSTALLATION INSTRUCT

The requirements in this chapter refer to the regulations of the Italian installation Standard UNI 10683. In any case, always comply with the regulations in force in the country of installation.

PELLETS

Wood pellets are obtained from compressing sawdust produced during the processing of natural dried wood (without paint). The compactness of the material is guaranteed by the lignin contained in the wood itself and allows pellets to be produced without glue or binders.

The market offers different types of pellets with characteristics that vary according to the wood mixtures used. The diameter varies between 6 and 8 mm, with a standard length ranging from 5 to 30 mm. Good quality pellets have a density that varies between 600 and over 750 kg/m³, with a moisture content that ranges from 5% to 8% of its weight.

Pellets have technical advantages besides being an ecological fuel, as the wood residue is used completely, thereby achieving cleaner combustion than that of fossil fuels.

Good-quality wood has a calorific value of 4.4 kW/kg (15% moisture, after about 18 months of seasoning), whereas that of pellets is 4.9 kW/kg. To ensure good combustion, the pellets must be stored in a dry place and protected from dirt. Pellets are usually supplied in 15 kg bags, therefore, storing them is very convenient.

Good quality pellets guarantee good combustion, thereby decreasing harmful emissions into the atmosphere.

15 Kg BAGS OF FUEL



The poorer the quality of the fuel, the more often the internal parts of the brazier and combustion chamber must be cleaned.

DINplus, Ö-Norm M7135 and Pellet gold are examples of the major quality certifications of pellets in the European market and guarantee that the following are complied with:

- Calorific value: 4.9 kWh/kg.
- Moisture content: max 10% of the weight.
- Percentage of ash: max 0.5% of the weight.
- Diameter: 5 – 6 mm.
- Length: max 30 mm.
- Content: 100% untreated wood with no added binding agents (max percentage of bark: 5%).
- Packaging: in bags made from environmentally friendly or biologically decomposable material.



The company strongly recommends using certified fuel for its products (DINplus, Ö-Norm M7135 or Pellet Gold). Poor quality pellets or others that do not comply with that specified previously compromises the operation of your product and can therefore render the warranty and product liability null and void.

2-INSTALLATION INSTRUCT

PRECAUTIONS REGARDING INSTALLATION



IMPORTANT!

Product installation and assembly must be carried out by qualified personnel.

The product must be installed in a suitable place for it to be regularly opened and routine maintenance to be performed. The environment must be:

- Compliant for proper operation.
- Equipped with an adequate smoke expulsion system.
- Equipped with ventilation intake from outside.
- Equipped with 230V 50 Hz power supply with an EC compliant earth system.

The product must be connected to a chimney or an internal or external vertical duct that complies with current regulations. The product must be positioned in such a way that the electrical socket is accessible.



IMPORTANT!

The product must be connected to a chimney or a vertical duct that can expel the smoke at the highest point of the building.

The smoke derives from the combustion of wood essence and if it comes in contact with or close to walls, the latter can become dirty. Moreover, utmost attention is required as they are almost invisible but very hot and can cause burns.

The holes of the external air inlet and the smoke outlet pipe must be drilled before positioning the product.

THE OPERATING ENVIRONMENT

For correct operation and even distribution of heat, the product must be placed where the air required for combustion can flow.

The volume of the environment must not be less than 15 m³.

The air must enter through permanent openings in the walls (near the product) that reach outside with a minimum section of 100 cm² without the protective grille (in the case of a non-Oyster installation, i.e. without external ducted combustion air).

These openings (air inlets) must be made in such a way that it is impossible for them to be obstructed in any way.

Air can also be drawn from adjacent rooms to the one that is to be ventilated, provided they have an external air inlet and are not used as a bedroom or bathroom or where there is a fire hazard, such as: a garage, wood shed or where flammable materials are stored, and applicable regulations must be strictly complied with.



If the product is placed too close to the wall it could cause overheating and damage the plaster (yellowing, cracking, etc.).

2-INSTALLATION INSTRUCT

POSITIONING AND RESTRICTIONS

In the case of simultaneous installation with other heating appliances, provide appropriate air inlets for each one (according to the instructions of each product).



The product cannot be installed (except for sealed or closed operation appliances with external ducted combustion air intake):

- in bedrooms or bathrooms;
- in rooms where there are liquid fuel appliances with continuous or intermittent operation that draw the combustion air from the room they are installed in;
- in rooms where there are B-type gas heating appliances, with or without domestic hot water production and interconnecting rooms;
- where another heating appliance is installed without an independent air flow.


It is forbidden to place the product in an explosive atmosphere.

MINIMUM DISTANCES



Room ventilation can only be set towards the rear wall if there is adequate insulated ducting of the hot air flow.

FLAT - FLAIR	Non-flammable walls	Flammable walls
Comfort Air	A = 2 cm B = 15 cm	A = 2 cm B = 20 cm



If particularly delicate objects are present, such as furniture, curtains or sofas the distance of the product must be significantly increased.



If the floor is made of wood, it is recommended to place a floor protection in accordance with the Standards in force in the country of installation.



Heat-sensitive or flammable objects cannot be placed near the product. Keep such objects at a minimum distance of 80 cm from the outermost point of the product.


2-INSTALLATION INSTRUCT

CONNECTION OF THE SMOKE EXHAUST DUCT

When drilling the hole for the smoke exhaust pipe, the possible presence of flammable materials must be considered. If the hole must be made through a wooden wall or thermolabile material, the **INSTALLER MUST** first use the relative wall fitting (minimum diam. 13 cm) and adequately insulate the pipe of the product that passes through it, using suitable insulating material (1.3 - 5 cm thick with minimum thermal conductivity 0.07 W/m²K).

The same minimum distance must be applied if the pipe of the product must pass through vertical or horizontal sections near the thermolabile wall.

It is recommended to use an insulated double-wall pipe in external sections in order to prevent condensation from forming. The combustion chamber works in negative pressure.



REAR VIEW OF A PELLET PRODUCT (EXAMPLE).

1) SMOKE OUTLET

2) COMBUSTION AIR INLET

2-INSTALLATION INSTRUCT

Always use pipes and fittings with appropriate seals that guarantee tightness.


It must be possible to inspect all sections of the flue duct and they must be removable for periodic internal cleaning (T-fitting with inspection hole). Position the product considering all the above requirements and instructions.



IMPORTANT!

The following conditions must be complied with when connecting the appliance to the chimney:

- **The smoke duct must be at least category T200 (or higher if required by the smoke temperature of the appliance) and P1-type (airtight).**
- **All 90° angles (max. 3) in the smoke exhaust duct must be preferably fitted with the relative T-fittings with inspection hole (See pellet product accessories).**
- **It is strictly forbidden to fit a mesh at the end of the exhaust pipe as it could cause the product to malfunction (due to clogging).**
- **It is forbidden to use counter-sloping pipes.**
- **The horizontal section of the smoke duct must not be longer than 2-3 m.**
- **It is also recommended not to exceed 6 metres in length with the pipe Ø 80 mm.**
- **The smoke duct must not cross rooms in which it is forbidden to install combustion appliances.**



COMBUSTION AIR (2)

During operation a certain amount of air is drawn from the room in which the product is installed and this air must be supplemented through an external air inlet.

2-INSTALLATION INSTRUCT

CONNECTION TO THE EXTERNAL AIR INTAKE

It is essential for the room where the product is installed to be adequately ventilated in order to guarantee sufficient air for proper combustion in the appliance. This is possible by means of suitable ventilation openings in the room itself or in an interconnected room through a permanent opening between the rooms (room ventilation is excluded in the case of installation with Oyster technology, where combustion air is ducted directly from outside).

For this purpose, drill a hole on the outer wall close to the product with a minimum section of 80 cm² (11 cm in diameter or 10x10 cm if rectangular, considering the protective grids), protected by a grid on the outside.

The air inlet must also:

- Be protected with a grid, metal mesh, etc. without reducing the net section.
- Be positioned in such a way so as not to be obstructed.
- Allow maintenance to be performed.
- Be directly interconnected with the room where the product is installed.
- In the case of ducting, up to 3.5 linear metres, increase the section by about 5%, whereas for longer ducts, increase it by 15%.



Remember that the ventilation grilles always have a useful section in cm² on one side. When choosing the grille and size of the hole, check that the useful section of the grille is larger or equal to the section required by the company for product operation.



IMPORTANT!

IMPORTANT! The air flow can also be drawn from an adjacent room to that of the room where the product is installed, provided the air can flow freely through permanent openings interconnected with the outside; air inlets connected to thermal units, garages, kitchens or bathrooms must be avoided.

CONNECTION TO THE CHIMNEY

The chimney is the fundamental element for smoke expulsion and must therefore comply with the following requirements:

- Be waterproof and thermally insulated.
- Be made of suitable materials that resist mechanical stress over time, heat, the effects of the combustion products and any possible condensation.
- Have a vertical set-up with deviations from the axis of no more than 45° and free of bottlenecks.
- Must be suitable for the specific operating conditions of the product and have the CE marking (EN1856-1, EN1443).
- Must be adequately sized for the draught/smoke expulsion requirements that are necessary for the product to operate correctly (EN13384-1).
- The internal section is preferably circular.
- In the case of a pre-existing product that has been used, it must be cleaned.






The chimney is fundamental for correct operation and safety of your product.

Hereunder are a few guidelines for a correct installation. Any alternative configurations must be suitably sized in accordance with the general method of calculation of UNI EN 13384-1.

2-INSTALLATION INSTRUCT

CONNECTIONS

CONNECTION TO THE CHIMNEY	CONNECTION TO AN EXTERNAL DUCT WITH AN INSULATED OR DOUBLE-WALL PIPE	CONNECTION TO THE CHIMNEY
<p>The internal dimensions of the chimney must not exceed 20x20 cm or 20 cm in diameter. In the case of larger dimensions or bad chimney conditions (e.g. cracks, poor insulation, etc.), it is advisable to fit a stainless steel pipe of suitable diameter throughout the length of the chimney right to the top.</p>	<p>The minimum internal dimensions of the external duct must be 10x10 cm or 10 cm in diameter and must not exceed 20x20 cm or 20 cm in diameter. Only stainless steel insulated (double-wall) pipes must be used, which are smooth on the inside and fixed to the wall. Flexible stainless steel pipes must not be used.</p>	<p>The connection between the product and the chimney or the smoke duct must not have an inclination that is less than 3% in the horizontal sections, which must have a maximum overall length of 2/3 m. The vertical section between one T-fitting and another (angle) must not be less than 1.5 m.</p>
		

1) WINDPROOF CHIMNEYPOT 2) CHIMNEY 3) INSPECTION HOLE




- Use adequate instruments to verify that there is a minimum draught of 5 Pa.
- Set-up an inspection hole at the bottom of the chimney to perform periodic checks and cleaning, which must be done annually.
- The connection to the chimney must be sealed and the fittings and pipes recommended by us must be used (CE marked in accordance with EN1856-2 with the minimum requisites: T200 and P1).
- You must ensure that a windproof chimneypot is installed in accordance with the regulations in force.
- This type of connection guarantees smoke expulsion even in the event of a temporary power cut.

2-INSTALLATION INSTRUCT

OPERATING PROBLEMS RELATED TO DRAUGHT DEFECTS IN THE CHIMNEY

Among all the weather and geographical conditions that affect chimney operation (rain, fog, snow, altitude a.s.l., exposure to sunlight, orientation to the cardinal points, etc.), the wind is certainly the most determinant. In fact, besides the thermal depression caused by the difference in temperature between inside and outside the chimney, there is another type of depression (or overpressure): dynamic pressure caused by the wind. An updraft always increases depression and therefore the draught. A horizontal wind increases depression provided the chimneypot has been installed properly. A downdraft always decreases depression and sometimes inverts it.



Besides the direction and force of the wind, the position of the chimney and the chimneypot with respect to the roof of the building and the surrounding landscape is also important.


The wind also affects chimney operation indirectly by creating overpressure and depression zones within the building as well as outside. An internal overpressure can be created in rooms that are directly exposed to the wind (2), which can enhance the draught in stoves and fireplaces, however, it can be counteracted by the external overpressure if the chimneypot is situated on the side exposed to the wind (1). On the other hand, a dynamic depression can be created in rooms that are opposite the wind direction (3), which competes with the natural thermal depression generated by the chimney, however, this can be compensated for (sometimes) by placing the smoke duct opposite the wind direction (4).



IMPORTANT!


The operation of the pellet product is significantly affected by the chimney layout and position.

Hazardous conditions can only be resolved by qualified personnel setting the product appropriately.




3-INSTALLATION AND ASSEMBLY

DRAWINGS AND CHARACTERISTICS FLAT COMFORT AIR DIMENSIONS (in mm)



3-INSTALLATION AND ASSEMBLY

FLAIR COMFORT AIR DIMENSIONS (in mm)



3-INSTALLATION AND ASSEMBLY

TECHNICAL CHARACTERISTICS	FLAT-FLAIR COMFORT AIR
Max. overall thermal power	8 kw / 6880 kcal
Min. overall thermal power	3,2 kw / 2580 kcal
Efficiency at Max	87,8%
Efficiency at Min	93,6%
Temperature of exhaust smoke at Max	160°C
Temperature of exhaust smoke at Min	90°C
Particulate	28 mg/Nm ³ (13% O ₂) - 19 mg/MJ
CO at 13% O ₂ at Min and at Max	0,042 – 0,012%
CO ₂ at Min and at Max	6,0% - 9,2%
Recommended draught at Max power	0,10 mbar - 10 Pa
Recommended draught at Min power	0,05 mbar - 5 Pa
Mass of smoke at Min and at Max	4,0 - 7,0 g/sec
Hopper capacity	30 litri
Type of pellet fuel	Pellet diameter 6-8 mm and size 5/30 mm
Pellet hourly consumption	Min ~ 0,7 kg/h* - Max ~ 1,8 kg/h*
Autonomy	At min ~ 29 h* - At max ~ 11 h*
Heatable volume m ³	172/40 – 197/35 – 229/30 **
Combustion air inlet	External diameter 50 mm
Smoke outlet	External diameter 80 mm
Electrical power consumption	Max 320 W - Med. 100 W
Supply voltage and frequency	230 Volt / 50 Hz
Net weight	125 kg
Weight with packaging	135 kg

* These data may vary according to the type of pellets used.

** Heatable volume based on the heat demand 40-35-30 m³ (respectively 40-35-30 Kcal/h per m³).

Tested according to EN 14785 in accordance with Directive 89/106/EEC (Construction Products).

3-INSTALLATION AND ASSEMBLY

PREPARATION AND UNPACKING

The **FLAT/FLAIR** stove is delivered on a pallet with a number of packages (fig. 2):

- The first contains the stove (fig. 1).
- The second contains the ceramic or serpentine panels (two sides + two tops).




FIGURE 1 - STOVE PACKAGING (front view)




FIGURE 2 - STOVE PACKAGING (rear view)

Open the package, remove the four brackets from the pallet (2 front and 2 rear), which block the stove to the pallet (fig. 3). The brackets are removed by loosening the two screws and removing the bracket.

Set the stove in the pre-selected place, making sure this complies with the requirements.

The product must always remain in a vertical position and handled solely with a cart. Pay particular attention to the door and its glass, protecting them from mechanical knocks that would compromise their integrity.

In any case, the product must always be handled with care. If possible, unpack the product near the place of installation. The packaging materials are neither toxic nor harmful, and therefore no particular disposal measures are required. The end user is responsible for product storage, disposal or possible recycling in compliance with the regulations in force.

3-INSTALLATION AND ASSEMBLY




FIGURE 3 - REMOVING THE PACKAGE SCREWS

3-INSTALLATION AND ASSEMBLY


Position the product without its cladding and connect it to the chimney. Once the connections are complete, assemble the cladding (ceramic or serpentine sides).

If the product must be connected to an exhaust pipe that goes through the rear wall (to enter the chimney), make sure not to force it in. Adjust the 4 feet (J) to level the stove for the smoke exhaust and the pipe to be coaxial. The ceramic/serpentine sides must not be fitted when the feet are adjusted as this is carried out inside the cladding. A rear foot is adjusted through the triangular hole on the back of the product (detail A).




Attention!


Do not use and/or force the smoke exhaust pipe when handling the product as it can be damaged.



1. TURN THE FEET CLOCKWISE TO LOWER THE PRODUCT.
2. TURN THE FEET ANTI-CLOCKWISE TO RAISE THE PRODUCT.



FOOT J.




DETAIL A.

3-INSTALLATION AND ASSEMBLY


CONNECTION OF THE SMOKE OUTLET PIPE

You can choose whether to release the smoke on the rear part or upper part of the product.

If you wish to connect the **smoke outlet to the upper part**, remove the cap with the three screws from under the top. Then insert the pipe until it engages with the smoke fitting.




REMOVE THE CAP FASTENED TO THE STRUCTURE OF THE PRODUCT WITH THREE SCREWS FROM UNDER THE TOP.



INSERTING THE PIPE FOR THE UPPER SMOKE OUTLET.

3-INSTALLATION AND ASSEMBLY

If you wish to connect the **smoke outlet to the rear part**, turn the T-fitting towards the rear of the product.
Then connect the pipes.



TURN THE T-FITTING FOR THE REAR SMOKE OUTLET.

3-INSTALLATION AND ASSEMBLY

CONNECTING THE HOT AIR DUCTING


The standard product has two fans installed for air distribution with the nozzle directed towards the front part of the stove. Therefore, the first important thing to decide is whether to channel the air or not. In line with this, turn the fan (2) for the air to be released towards the rear part.



Attention: make sure the plug has been disconnected from the socket before performing any operation.


How to turn the fan.

- Remove the ceramic/serpentine top.
- Remove plate A.
- Remove the two screws "B" that fasten the fan to the structure of the product.
- Pull it slightly out from its seat for it to turn (it does not have to be removed!).
- Turn the whole fan 180°.
- Fasten the fan to the structure once again with the two screws "B".
- Fasten plate "A".
- Set the top in place and insert the plug.




3-INSTALLATION AND ASSEMBLY

FAN 2 TURNED FOR REAR AIR.



The air can be channelled by fastening a flexible pipe on the rear part of the product with a clamp, in line with the hole on the upper part.



The air can now be released from the front and rear, only from the front or only from the rear.
These channels can also be walled in (SEE OPTIONALS).



Room ventilation can only be set towards the rear wall if there is adequate insulated ducting of the hot air flow.




The air outlet pipe can become very hot, approx. 200°C: therefore, it must be adequately insulated with suitable material, especially points that could come in contact with flammable surfaces or parts that are affected by heat (e.g. change in shades, wiring ducts, plasterboard, etc.). Moreover, persons and animals must be protected from accidental or intentional contact. In any case, comply with the regulations and laws in force in the region where the product is installed.

3-INSTALLATION AND ASSEMBLY



It is recommended to insulate the entire length of the pipe in order to reduce dispersion and increase heat output in the room.



If the wall that is to be drilled through is made of flammable material, the **INSTALLER MUST** adequately insulate the pipe of the stove that passes through it, using suitable insulating material (1.3 - 5 cm thick with min. thermal conductivity $0.07 \text{ W/m}^{\circ}\text{K}$). However, the pipe inserted in the wall must be adequately insulated in order not to disperse heat and soundproof the released air.

3-INSTALLATION AND ASSEMBLY


ASSEMBLING THE CLADDING

ASSEMBLING THE SIDE PANELS

The product is supplied with the ceramic or serpentine panels packaged separately, therefore unpack all the parts before proceeding with the assembly. The ceramic and serpentine stone panels are assembled in the same way.


Follow the sequence below to assemble the panels:

- Pins "b" on the lower part of the ceramic or stone panel **A** must be fitted into the holes of the structure of the stove. Then fasten the panel to the structure - **pos.c** - with the screws supplied (two screws at the top).



3-INSTALLATION AND ASSEMBLY


- Panel **B** can be fastened by following the procedures implemented to assemble panel **A**. The pins on the lower part of the panel - **pos. d** - must enter the holes in the structure, whereas two screws on the upper part of the panel, block it to the structure - **pos. f**. Panel **B** rests on the two adjustable screws "e". Panels **A** and **B** could touch or the gap between may be too wide, therefore, adjust screw "e" to resolve the problem.



3-INSTALLATION AND ASSEMBLY

ASSEMBLING THE TOP

The top does not require particular fastening as it is only placed on the structure of the product in line with the relative vibration dampers. Therefore, once panels **A** and **B** are fitted, parts **C** and **D** can be assembled with the hopper cover **E**.



3-INSTALLATION AND ASSEMBLY

ASSEMBLING THE AIR FILTER

The cylindrical filter is already fitted inside the product.

If it must be cleaned, slightly loosen the screw knob on the air inlet pipe, remove the filter, clean it and then set it and block it in place by tightening the knob.



ATTENTION!

The stove must never be operated without the air filter. The manufacturer cannot be held liable for any damage caused to the internal components if this requirement is not complied with.



ASSEMBLING/REMOVING THE AIR FILTER.


OPENING/CLOSING THE DOOR



ATTENTION!

The door must be closed properly for the product to work correctly.

The door of the Flat/Flair stove is opened by inserting the cold handle on the opening hook of the door, lifting and pulling.



OPENING THE DOOR.


ELECTRICAL CONNECTION

First connect the power cable to the side of the stove and then to a wall socket.

The main switch at the side must only be activated when the stove is used; otherwise, it is advisable to keep it off.



It is recommended to disconnect the power cable when the product is not used.



ELECTRICAL CONNECTION


3-INSTALLATION AND ASSEMBLY

BEFORE START-UP

GENERAL PRECAUTIONS

Remove all components that could burn from the brazier and the glass (manual, various adhesive labels and any polystyrene).

Check that the brazier is positioned correctly and rests properly on the base.



After a long period of inactivity, remove any pellets left in the hopper (**using a vacuum cleaner with a long pipe**), as they could have absorbed moisture, thereby altering their original characteristics and no longer being suitable for combustion.



The first start-up may not be successful as the feed screw is empty and does not always manage to load the required amount of pellets in the brazier in time for the fire to be regularly ignited.



CANCEL THE FAILED START-UP ALARM STATUS BY BRINGING SELECTOR "D" TO OFF. REMOVE THE PELLETS FROM THE BRAZIER AND REPEAT START-UP.

If a flame does not ignite after a number of failed start-ups, even though the pellet supply is correct, make sure the brazier is set in place correctly, which must be **interlocked in its seat and clean from any ash deposits**. If no anomaly is found during this inspection, there may be a problem with the product components or installation may not be correct.



REMOVE THE PELLETS FROM THE BRAZIER AND CONTACT AN AUTHORISED TECHNICIAN.



Avoid touching the stove during the initial start-up, as the paint hardens during this phase. If you touch the paint, the steel surface may be exposed.

If necessary, touch up the paint with the spray can of the specific colour (see "Pellet stove accessories").

3-INSTALLATION AND ASSEMBLY



It is good practice to guarantee effective ventilation in the room during the initial start-up, as the stove will emit some smoke and smell of paint.

Do not stand close to the stove and air the room. The smoke and smell of paint will disappear after about an hour of operation, however, remember they are not harmful in any case.

The stove will be subject to expansion and contraction during the start-up and cooling phases, therefore light creaking noises may be heard.

This is absolutely normal as the structure is made of laminated steel and must not be considered a defect.

It is extremely important to make sure the stove is not immediately overheated and the temperature is increased gradually starting from the low power.




This will prevent damaging the ceramic or serpentine tiles, the welds and the steel structure.



DO NOT EXPECT HEATING EFFICIENCY IMMEDIATELY!

SETTINGS TO BE CARRIED OUT BEFORE THE INITIAL START-UP

Once the power cable is connected in the rear part of the stove, bring the switch to position (I). Switch the stove on and off by pressing key A on the remote control and LEDs B or C on the emergency panel will light up according to the mode of the stove.



3-INSTALLATION AND ASSEMBLY


LOADING THE PELLETS

Fuel is loaded by lifting the cover on the upper part of the product. Slowly pour the pellets into the hopper.

Be careful as the cover could become very hot.

LIFT THE COVER.

INSERT THE PELLETS.



No other type of fuel other than pellets, in compliance with above-mentioned specifications, is to be inserted into the hopper.

4-LCD REMOTE CONTROL

GENERAL SPECIFICATIONS OF THE LCD REMOTE CONTROL

The remote control works at a transmission frequency of 434.5 MHz.

Power the product with 3 AAA batteries as follows:

- Remove the cover of the battery compartment by pressing and lifting the point indicated by the arrow.
- Insert the batteries with the correct polarity (+) and (-).
- Close the cover of the battery compartment.

The time must be set when the remote control is switched on.

The remote control has a special icon on the display to indicate when the batteries are almost flat. If the flat battery icon appears, the batteries are almost flat and the remote control is about to go off.




Used batteries must be disposed of separately in special containers.



GRAPHIC APPEARANCE

Reference will often be made to the keys. Always keep the figure at hand for simplicity's sake.



4-LCD REMOTE CONTROL

LCD REMOTE CONTROL OPERATION

GENERAL RULES

Press key **A** for 1" to switch the product on and off. All changes are made with keys **C**. Key **E** is used to confirm the changes. Key **B** is used to select the product operating mode. Key **D** is used to browse the **VENTILATION** and **SLEEP** settings (see "Various settings").

Whichever the mode is, press key **A** briefly (or leave the keypad idle for 7") to go back to the initial display.

INITIAL SETTINGS

SETTING THE TIME

The time/day setting is accessed by pressing keys **B+E** simultaneously for 3"; regardless whether the remote control is on or off.

The hour digits will start to flash, which can be modified with keys **C**. Press key **E** to confirm the changes.

The minute digits will then start to flash. Follow the same procedure to modify and confirm the setting and the time display setting (12h or 24h) will then be accessed and lastly, the day will start to flash. Confirm this data to exit the settings.

NOTE: each time the remote control is powered, the time is reset and the display automatically enters the time setting.

°C - °F SETTING

The unit of temperature measurement is changed from Celsius to Fahrenheit and vice versa by pressing key **B** for 5" while the product is off.

SETTING THE OPERATING MODE

One of the following 4 operating modes can be set via key **B** while the remote control is on. The 4 basic displays are shown, respectively, in figures 1-2-3 and 4:

Manual, Automatic, Timer and Eco mode.

MANUAL MODE (MAN)

This mode allows the flame power (changed directly via keys C) and ventilation to be set manually in 5 levels + auto (see "Various settings"), Figure 1.

AUTOMATIC MODE (AUTO)

This mode allows the desired room temperature to be set and the appliance will automatically adjust the flame power to reach it. The ventilation can be adjusted in 5 levels + auto (see "Various settings"), Figure 2.



FIGURE 1
MANUAL MODE.




FIGURE 2
AUTOMATIC MODE.

4-LCD REMOTE CONTROL

TIMER MODE (TIMER)

Select this operating mode to switch the product on and off automatically, according to 6 customised time bands (P1 – P6). The following can be set for each time band:

- Start-up time.
- Shutdown time.
- Desired room temperature during that time band.
- Days of the week when the time band is to be activated.

Days of the week when the time band is to be activated. When the product is switched on (manually via button A or automatically via a time band), it operates in the automatic mode, described above. A time band appears automatically when it is active (P1 in figure 3) and the desired temperature is changed to the value set in the time band. However, the user can always modify this value as desired and in real time.

Refer to “Timer Settings” to learn how to set the time bands.




FIGURE 3

ECO MODE (ECO)

This mode is activated/deactivated by pressing key B for 5” on the remote control while it is switched on.

ECO is an automatic mode with the only difference that if the set temperature is reached and remains so for the subsequent 20 minutes (despite flame modulation), the product is switched off and remains on stand by until the room temperature drops 2 degrees below the desired temperature (and in any case for at least 5 minutes from the last shutdown). The product is then switched on again, Figure 4.

If the room is not sufficiently insulated, flame modulation does not allow the set temperature to be met for 20 consecutive minutes and the product will not go off.

NOTE: it is recommended to use the ECO mode only in well-insulated rooms in order to prevent start-up and shutdown from occurring within short periods of time.

The remote control remains on even when the product is off when in ECO mode, in order to indicate that this shutdown is only temporary. Obviously, if the product is switched off from key A, ECO mode is exited and the product remains off.

Up to 6 automatic start-up and shutdown time bands (E1 – E6) can also be set in ECO mode, which are independent from those of TIMER mode (P1 – P6). If they have been activated, TIMER-ECO appears on the display (figure 5) permanently, even if the remote control is switched off.

Refer to “Timer Settings” to learn how to set the time bands.

NOTE: if the remote control is switched off in TIMER mode, ECO mode can only be re-activated by the user (key A) or when started-up by the next valid time band. Combined use of TIMER and ECO modes requires a good knowledge of the product operating logic.



FIGURE 4



FIGURE 5

4-LCD REMOTE CONTROL

VARIOUS SETTINGS

ROOM VENTILATION

The room ventilation can be adjusted as desired in all 4 operating modes described earlier on. Simply follow the steps below: press key D on the initial display to access the **VENTILATION** setting. Then press key C to set the desired ventilation by selecting one of the 5 levels available. The “auto” option can also be selected, which automatically links the room ventilation speed to the flame level.

In brief:

flame set to 1 > ventilation set to 1; flame set to 3 > ventilation set to 3; flame set to 5 > ventilation remains set to 3 (for silent operation as it is in automatic mode).

The speed of each fan (identified with 1 or 2 above the level bars) in products with 2 fans (comfort air models) can be scrolled and set via key D.

NOTE: if the remote control is replaced with a new one and the default settings must be changed, proceed as follows: press keys D + E simultaneously for 10 seconds while the remote control is switched on (until the flashing number disappears). Press key C to select 1 or 2 according to the product to which the remote control is to be paired, and press E to exit.




FIGURE 6

SLEEP FUNCTION

The sleep function allows a shutdown time to be set quickly. This function is only available in the **MAN** and **AUTO** modes. It is set as follows: from the **VENTILATION** setting (press key D - see the previous paragraph), press key D again to access the **SLEEP** setting.

The shutdown time is set in 10 minute intervals via key C. Confirm via key D or E and the display returns to the initial page on which the sleep shutdown time remains displayed. Disable the **SLEEP** function by simply accessing the setting and decreasing the time until dashes are displayed and then confirm.




FIGURE 7

4-LCD REMOTE CONTROL

TIMER SETTINGS

DISPLAY THE TIMER TIME BANDS

Simply press key **D** for 2" to display the time bands in **TIMER** mode. The 6 time bands can be scrolled through with key **C**, thereby verifying all the saved settings. Press key **D** or **A** to return to the initial display.



FIGURE 8

MODIFYING THE TIMER TIME BANDS

Modify a time band by displaying it as described in the previous paragraph and then press key **E** briefly.

The first parameter that can be set will start to flash, i.e. the room temperature. Press key **C** to modify the value and key **E** to confirm and move on to the next parameter. The parameters of a time band can be set in the following order:

- Room temperature. Can be set between 5° and 35°C. 2 dashes "--" appear if set below 5°C or above 35°C, and if this is confirmed, the program is deactivated (therefore, the product will not be switched on).
- Start-up time. The value is adjusted in 10 minute intervals (from 00:00 to 23:50).
- Shutdown time. The value is adjusted in 10 minute intervals (from 00:10:00 to 24:00).
- Days of the week when the program is to be activated. Monday (MO) will start to flash, followed by the other days of the week. Use key **C** to activate/deactivate the day. The activated days will be displayed on a dark background. When the Sunday (SU) setting is complete, press key **E** to exit the editing page and return to the time bands display.

Press key **D** at any time to save all the changes made (confirmed by pressing key **E**), exit the time band editing page and return to the time bands display. Press key **A** (or leave the keypad idle for 30") to go directly to the initial display, saving all the changes made and confirmed with key **E**.

ACTIVATING THE TIMER-ECO TIME BANDS

6 customised start-up and shutdown time bands (**E1 – E6**) can be activated in the **ECO** mode: press key **D** for 2" and the **TIMER** activation/deactivation function will appear. If the **ON** option is confirmed, the 6 **TIMER-ECO** time bands are accessed and can be modified as described earlier on for the **TIMER**. If the **OFF** option is confirmed, the **TIMER** is disabled and the product returns to the **ECO** mode with no time bands activated.





FIGURE 9

5-EMERGENCY PANEL

EMERGENCY PANEL

There is an emergency panel on the product side, designed for any malfunction to be detected and product control if the remote control should malfunction.



KEY

A	Three-digit display that indicates a variety of product information besides the identification code of any malfunction.
B	GREEN LED that indicates: <ul style="list-style-type: none"> • OFF= The product is off. • FLASHING ON= The product is starting up. • FIXED ON= The product is on.
C	RED LED that indicates: <ul style="list-style-type: none"> • OFF= The product is on. • ON AND FLASHING SLOWLY= The product is shutting down. • ON AND FLASHING QUICKLY= The product is in alarm status (accompanied by a buzzer for the first 10 minutes). • FIXED ON= The product is off.
D	3-position selector for the following functions: <ul style="list-style-type: none"> • OFF= The product is switched off manually without the remote control. • REMOTE= The product can only be controlled via remote control. • ON= The product is switched on manually without the remote control.
E	3-position selector for the power selection: <ul style="list-style-type: none"> • MIN= The product runs at MINIMUM power without the remote control and with selector 4 set to ON. • MED= The product runs at MEDIUM power without the remote control and with selector 4 set to ON. • MAX= The product runs at MAXIMUM power without the remote control and with selector 4 set to ON.
F	Button for diagnostic functions regarding the product operation mode.
G	Button to connect the product to a new remote control.



SELECTOR "D" MUST BE SET TO THE "REMOTE" POSITION FOR THE PRODUCT TO BE REMOTE CONTROLLED.

5-EMERGENCY PANEL


EMERGENCY PANEL START-UP/SHUTDOWN

If the remote control is faulty or the batteries are flat, the product can be operated in safe mode via the rear emergency panel. In this configuration, the product can only work in manual mode and one of 3 power levels can be selected.

- **APPLIANCE START-UP WITHOUT THE REMOTE CONTROL.**
Switch the product on by bringing selector "D" to the **ON** position. The RED LED goes off upon start-up, whereas the GREEN LED starts to flash until the start-up phase is complete. Once the product runs smoothly, the GREEN LED remains on.
- **SELECTING THE POWER WITHOUT THE REMOTE CONTROL.**
One of three heating powers **MIN-MED-MAX** can be selected (selector "E"):
The **MINIMUM** power corresponds to the 1st power.
The **MEDIUM** power corresponds to the 3rd power.
The **MAXIMUM** power corresponds to the 5th power.
- **APPLIANCE SHUTDOWN WITHOUT THE REMOTE CONTROL.**
Switch the product off by bringing selector "D" to the **OFF** position.



Once the remote control is restored, remember to set selector "D" back to the "REMOTE" position, otherwise the product will ignore the remote control commands.




5-EMERGENCY PANEL

LOAD THE FEED SCREW

This function can only be activated when the stove is off and allows the pellets to be loaded into the feed screw (loading system). It can be used each time the pellets finish in the feed screw and hopper (see alarm A02). It is useful to prevent failed start-ups (alarm A01) due to the hopper being empty.

The LOAD FEED SCREW function is activated as follows (with the stove off): bring selector "D" on the emergency panel to OFF and press key **TEST** on the same panel three consecutive times. Wait a few seconds and FEED SCREW will flash on the display.

Press the TEST key once again when the pellets begin to fall into the brazier to end the LOAD FEED SCREW function and proceed with the stove start-up.



6-SAFETY DEVICES AND ALARMS

SAFETY DEVICES

The product is supplied with the following safety devices:

SMOKE TEMPERATURE PROBE

Detects the temperature of the smoke, thereby enabling start-up or stopping the product when the temperature drops below the preset value.

PELLET HOPPER SAFETY THERMOSTAT

If the temperature exceeds the preset safety value, it immediately stops the product, which must cool down before being restarted. Selector "D" must be set to "Off" for the product to be restored.

ELECTRICAL SAFETY

The product is protected against sudden changes in current by a main fuse in the power supply panel on the rear part of the product. Other fuses that protect the electronic boards are found on the latter.

SMOKE FAN FAULT

If the fan stops, the electronic board promptly blocks the supply of pellets and the alarm is displayed.

GEAR MOTOR FAULT

If the gear motor stops, the product continues to work until the minimum cool level is reached.

TEMPORARY POWER CUT

If a power cut occurs during operation, the product automatically sets itself in cooling mode when the power is restored and then restarts.

FAILED START-UP

If no flame is developed during start-up, the product will go into alarm status.



IT IS FORBIDDEN TO TAMPER WITH THE SAFETY DEVICES.



The product can be started-up and the automatic function of the probe restored only after having eliminated the cause that triggered the safety system. This manual will help you understand which anomaly has occurred, and explain how to intervene according to the alarm message displayed on the product.

6-SAFETY DEVICES AND ALARMS

ALARM ALERTS

If an operating anomaly occurs, the product enters the shutdown phase due to an alarm and informs the user regarding the type of fault by means of a 3 digit code that remains displayed on the emergency panel.

The alarm is indicated permanently by the relative 3 digit code, a flashing red LED that lights up on the emergency panel and an intermittent buzzer for the first 10 minutes. Read the instructions in the following 2 paragraphs to cancel the alarm status and restore the normal operating mode of the stove. The following table describes the possible alarms indicated by the product, associated to the respective code that appears on the emergency panel and helpful tips to resolve the problem.

DISPLAY MESSAGE	TYPE OF PROBLEM	SOLUTION
A01	The fire does not ignite.	Check the level of pellets in the hopper. Check that the brazier rests correctly in its seat and has no visible deposits of unburned pellets. Check whether the start-up spark plug becomes hot.
A02	The fire goes off abnormally.	Due to the hopper being empty (no fuel).
A03	The pellet hopper temperature exceeds the intended safety threshold. The structure overheats due to reduced heat dissipation.	The structure is too hot because the product has been used for too long at the maximum power or due to poor ventilation or because the air fans are faulty. When the product is sufficiently cold, press button B on the control panel or OFF on the remote control to delete alarm A03. Once the alarm is deleted, the appliance can be switched on.
A04	The temperature of the exhaust smoke has exceeded the preset safety limits.	The appliance switches off automatically. Let the product cool down for a few minutes and then switch it on again. Check the smoke expulsion and the type of pellets used.
A05	Clogged flue-wind-door open.	Check the smoke duct and make sure the door is closed.
A06	The smoke extractor fails to guarantee sufficient primary air, required for a correct combustion.	Insufficient draught or clogged brazier. Verify whether the brazier is clogged and clean it, if necessary. Check and if necessary clean the smoke duct and air inlet.
A08	Faulty smoke fan.	Verify whether the smoke fan compartment is clean, and particularly if it is blocked by dirt. If this does not suffice, the smoke fan is faulty. Contact an authorised service centre to have it replaced.
A09	The smoke probe is faulty and does not detect the exhaust smoke temperature correctly.	Contact an authorised service centre to have the component replaced.

6-SAFETY DEVICES AND ALARMS

A10	The spark plug is faulty.	Contact an authorised service centre to have the component replaced.
A11	Pellet supply fault.	Contact an authorised service centre to have the component replaced.
A12	The remote control has been out of the product reception range for over 3 hours (or the batteries are flat). NOTE: the appliance does not enter the shutdown phase due to an alarm only in such a case, and continues to work in the mode set by the remote control via the last command.	Move the remote control within the product reception range (or change the batteries of the remote control if they are flat). The alarm alerts will disappear as soon as the appliance receives a new signal from the remote control. A simple way of forcing signal transmission to the product is by pressing button 4 (which changes the operating mode from manual to automatic and vice versa).
A13	General fault in the electronic control unit.	Contact an authorised service centre to have the component replaced.
A14	Faulty air flow rate sensor.	This alarm does not block the system and only a warning screen is displayed. Contact an authorised service centre to have the component replaced.
SER	Routine maintenance alert.	This flashing message upon start-up indicates that the preset operating hours before maintenance is due have elapsed and a qualified technician, recommended by the manufacturer, must be contacted for maintenance to be performed.

DELETING THE ALARM STATUS

Follow the procedure described below to restore normal product operation after an alarm has been triggered:

- Set selector D on the rear emergency panel to OFF for a few seconds until the 3 digit alarm identification code disappears. The red LED stops flashing and the alarm buzzer is silenced by performing the steps below.
- Set selector D back to the REMOTE position for product operation to be remote controlled.
- Switch the remote control off and then on again if the product is to be switched on.



Only if alarm A12 is triggered (no communication between the remote control and the product), the appliance remains on according to the last mode set and automatically exits the alarm mode when the first signal is received from the remote control.

6-SAFETY DEVICES AND ALARMS

BLOCKED PRODUCT

The following may cause the product to be mechanically blocked:

- The structure overheats (“**A03**”).
- The smoke is overheated (“**A04**”).
- During product operation, air that has not been controlled in the combustion chamber has entered or the chimney is clogged (“**A05**”).

SOLUTIONS:

If “**A03**” appears, the structure is too hot because the product has been used for too long at the maximum power or due to poor ventilation or because the air fans are faulty.


When the product is sufficiently cold, press button B on the control panel to delete alarm A03. Once the alarm is deleted, the product can be switched on.

If “**A04**” appears, the product will shutdown automatically, let it cool down for a few minutes and then switch it on again. Delete the alarm and switch the product on again.


If “**A05**” appears, the door has been left open for too long or a significant amount of air has entered (e.g. missing smoke fan inspection cap). If these causes are excluded, check and if necessary clean the smoke duct and chimney.

Only after having eliminated the cause permanently can the product be switched on again.

7-MAINTENANCE AND CLEANING



EXAMPLE OF A CLEAN BRAZIER



EXAMPLE OF A DIRTY BRAZIER



ATTENTION!

All the cleaning operations of all parts must be performed with a completely cold product and the plug disconnected. The product requires little maintenance if used with certified good quality pellets.

DAILY OR WEEKLY CLEANING PERFORMED BY THE USER BEFORE EACH START-UP

Clean the ash and any deposits in the brazier that could clog the air passage holes.

If the pellets in the hopper finish, unburned pellets may accumulate in the brazier. Always empty the residue in the brazier before starting-up.




REMEMBER THAT ONLY A CORRECTLY POSITIONED AND CLEAN BRAZIER CAN GUARANTEE START-UP AND OPTIMAL OPERATION OF YOUR PELLET PRODUCT.

For the brazier to be cleaned properly, remove it from its housing completely and thoroughly clean all the holes and the grate on the bottom. If good quality pellets are used, you will normally only need to use a brush to restore the optimal operating conditions of the component.

CHECKS TO BE PERFORMED EVERY 2/3 DAYS

Clean and empty the ash pan, being careful of hot ashes.

Only if the ash is completely cold can a vacuum cleaner be used to remove it. In this case, use an adequate vacuum cleaner to remove particles that are not so small. Experience and the quality of the pellets will determine the cleaning frequency required. **However, it is recommended not to exceed 2 or 3 days.**



CLEANING THE ASH COLLECTION COMPARTMENT

7-MAINTENANCE AND CLEANING

CLEANING THE GLASS

It is recommended to clean the ceramic glass with a dry brush, or if it is very dirty, spray a little specific detergent and clean with a cloth.



ATTENTION!

Do not use abrasive products and do not spray the glass spray cleaner on the painted parts or the door gaskets (ceramic fibre cord).

PERIODIC CLEANING PERFORMED BY A QUALIFIED TECHNICIAN

CLEANING THE HEAT EXCHANGER

The compartment through which the exhaust smoke passes must be cleaned at the of the winter season.

This cleaning process is mandatory in order to facilitate the general removal of all combustion residue, before it becomes very difficult to remove it due to the humidity compacting it over time.

If necessary, clean it more often.



It is good practice to guarantee effective ventilation in the room while cleaning the product.

CLEANING THE EXCHANGER:

When the stove is cold, open the door, remove pan "M" and brazier "N"; remove the side plates "O" and "P" by turning them slightly inwards for them to come out of their grooves and then pull them towards you (be careful as they can break easily).

Once the side plates are removed, lift plate "H" slightly, tilt it downwards and remove it.

Then remove the upper plate "Q" by inserting the cold handle or another tool in slot "Y" on the upper part and lifting plate "Q". Remove it from its seat by lifting it and then tilting it slightly downwards.

Scrape the walls of the firebox with a rigid rod or a bottle brush into plate "Q" that has just been removed, for the ash to fall into the lower ash collection compartment.

Once the upper exchanger is cleaned, remove plate "L" after having removed the two screws, and use the nozzle of a vacuum cleaner to remove the ash and soot accumulated in the lower exchanger and around brazier "N". Clean and reassemble everything.

7-MAINTENANCE AND CLEANING

CLEANING THE SMOKE DUCT AND GENERAL CHECKS:

Clean the smoke exhaust, especially around the T-fittings, curves and any horizontal sections.
Remove the side to clean the T-fitting.

For information on cleaning the flue, contact a chimney sweeper.


Check the tightness of the ceramic fibre gaskets on the door of the product.

If necessary, order new replacement gaskets from the retailer or contact an authorized service centre to carry out this task.




ATTENTION:


The frequency with which the smoke exhaust must be cleaned depends on the use of the stove and the type of installation. The company recommends contacting an authorised service centre for end-of-season maintenance and cleaning as the above-mentioned operations will be performed together with a general inspection of the components.



CLEANING THE FLAT STOVE EXCHANGER



CLEANING THE FLAT STOVE T-FITTING




7-MAINTENANCE AND CLEANING

END-OF-SEASON SHUTDOWN

At the end of each season, before switching the product off, it is recommended to remove all the pellets from the hopper with a vacuum cleaner that has a long pipe.

The appliance must be disconnected from the mains when it is not used. It is recommended to remove the power cable for additional safety, especially in the presence of children.

The service fuse may have to be replaced if the control panel display does not go on when the product is next switched on by pressing the main switch on its side. There is a fuse compartment on the side of the product, under the power socket. After having disconnected the plug from the socket, use a screwdriver to open the cover of the fuse compartment and if necessary, replace them (3.15 A delayed).



CHECKING THE INTERNAL COMPONENTS



ATTENTION!

The internal electromechanical components must only be checked by qualified personnel whose technical expertise includes combustion and electricity.

It is recommended to perform this routine maintenance annually (with a scheduled service contract), which focuses on a visual and functional verification of the internal components. The following is a summary of the necessary checks and/or maintenance for the product to work correctly.

PARTS/INTERVAL	1 DAY	2-3 DAYS	30 DAYS	90 DAYS	1 YEAR
Brazier	•				
Ash collection compartment		•			
Ash pan		•			
Glass		•			
Complete exchanger					•
Smoke duct			•		
Door gasket					•
Air filter			•		•
Remote control battery (if purchased/optional)					•

8-PROBLEMS/CAUSES/SOLUTIONS



ATTENTION!

All repairs must only be carried out by a specialised technician, with the product switched off and the plug disconnected.

If the product is NOT used as described in this manual, the manufacturer declines all liability for any damage caused to persons and property.

All the necessary measures and/or precautions must be adopted when performing maintenance, cleaning and repairs.

- Do not tamper with the safety devices.
- Do not remove the safety devices.
- Connect the product to an efficient smoke expulsion system.
- Verify that the room in which the appliance will be installed is adequately ventilated.

ANOMALY	POSSIBLE CAUSES	SOLUTIONS
The pellets are not fed into the combustion chamber.	The pellet hopper is empty.	Fill the hopper with pellets.
	Sawdust has blocked the feed screw.	Empty the hopper and remove the sawdust from feed screw by hand.
	Faulty gear motor.	<i>Replace the gear motor.</i>
	Faulty electronic board.	<i>Replace the circuit board.</i>
The fire goes out or the appliance stops automatically.	The pellet hopper is empty.	Fill the hopper with pellets.
	The pellets are not fed.	See the previous anomaly.
	The pellet temperature safety probe has been triggered.	Let the product cool down, restore the thermostat until the problem is resolved and switch the product back on. If the problem persists contact Technical Assistance.
	The door is not closed properly or the gaskets are worn.	<i>Close the door and replace the gaskets with original ones.</i>
	Unsuitable pellets.	Change the type of pellets with those recommended by the manufacturer.
	Low pellet supply.	<i>Have the fuel flow rate checked by Technical Assistance.</i>
	The combustion chamber is dirty.	Clean the combustion chamber in accordance with the installation guide.
	Clogged outlet.	Clean the smoke duct.
	Faulty smoke extraction motor.	<i>Check the motor and replace it, if necessary.</i>
Triggered clogged flue alarm.	<i>Verify whether the smoke duct is clogged.</i>	


8-PROBLEMS/CAUSES/SOLUTIONS

ANOMALY	POSSIBLE CAUSES	SOLUTIONS
The product works for a few minutes and then switches off.	Start-up phase is not completed.	Repeat start-up.
	Temporary power cut.	Wait for the automatic restart.
	Clogged smoke duct.	Clean the smoke duct.
	Faulty or malfunctioning temperature probes.	<i>Check and replace the probes.</i>
	Faulty spark plug.	<i>Check the spark plug and replace it, if necessary.</i>
Pellets accumulate in the brazier, the glass of the door gets dirty and the flame is weak.	Insufficient combustion air.	Make sure there is an air inlet in the room and it is not clogged. Check that the combustion air filter on the Ø 5 cm air inlet pipe is not clogged. Clean the brazier and check that all the holes are clear. Perform a general cleaning of the combustion chamber and the smoke duct. Check the state of the door gaskets.
	Damp or unsuitable pellets.	Change the type of pellets.
	Faulty smoke evacuation motor.	<i>Check the motor and replace it, if necessary.</i>
The smoke evacuation motor does not work.	The product is not powered.	Check the mains voltage and the protection fuse.
	The motor is faulty.	<i>Check the motor and capacitor and replace them, if necessary.</i>
	The electronic board is faulty.	<i>Replace the electronic board.</i>
	The control panel is faulty.	<i>Replace the control panel.</i>
The convection air fan never stops.	Faulty or malfunctioning temperature control probe.	<i>Check the probe and replace it, if necessary.</i>
	Faulty fan.	<i>Check the fan and replace it, if necessary.</i>
The remote control does not work.	The remote control battery is flat.	Replace the batteries.
	Faulty remote control.	Replace the remote control.

8-PROBLEMS/CAUSES/SOLUTIONS

The product always runs at maximum power when in automatic mode.	The room thermostat is in the maximum position.	Set the thermostat temperature.
	Faulty temperature probe.	<i>Check the probe and replace it, if necessary.</i>
	Faulty or malfunctioning control panel.	<i>Check the panel and replace it, if necessary.</i>
	Thermostat is set to minimum.	Set the thermostat temperature.
The appliance does not go on.	No power supply.	Check that the plug is inserted and the main switch is in the "I" position.
	Faulty pellet probe.	Wait for the pellet or water tank to cool down and restart the product.
	Fuse blown.	Replace the fuse.
	Clogged smoke exhaust or smoke duct.	Clean the smoke exhaust and/or the smoke duct.
	An alarm has been triggered.	Verify the type of alarm and proceed accordingly.

9-WIRING DIAGRAMS



MOTHERBOARD WIRING KEY

- | | | | |
|----|---------------------|-----|---------------------------------|
| 1. | EMERGENCY PANEL | 8. | GEAR MOTOR |
| 3. | SMOKE PROBE | 9. | CONTACT THERMOSTAT |
| 4. | MODEM CONNECTION | 10. | AIR FAN |
| 5. | SWITCH | 11. | SMOKE EXPULSION FAN REV CONTROL |
| 6. | SPARK PLUG | 12. | AIR DOOR PROBE |
| 7. | SMOKE EXPULSION FAN | | |

N.B. The wiring of the individual components is fitted with pre-wired connectors of different sizes.



MCZ GROUP S.p.A.

Via La Croce n°8

33074 Vigonovo di Fontanafredda (PN) – ITALY

Telephone: 0434/599599 r.a.

Fax: 0434/599598

Internet: www.mcz.it

e-mail: mcz@mcz.it

For further technical information
regarding installation or operation please contact the
TECHNICAL ASSISTANCE – AFTER-SALES DEPARTMENT

Monday to Friday

8.00 to 12.00 and 14.00 to 18.00